



Top Panel
Trellis Style Shown,
Plain Style Available



Standard Panel
Height 500mm, Standard
length 1.83m (6') can be
customised on request



**Left Hand Post
Cover**



Centre Post Cover



**Right Hand Post
Cover**



Step 1 : Secure your
structural inner posts
firmly on site.



Step 2 : Place
appropriate post
cover over inner post.



Step 3 : Slide post
cover down fully
over inner post.



Step 4 : Hang top panel over post covers. The top panel will hook over the post cover as shown. Make sure top panel is securely hooked on both post covers. Note: This is a back view of the fence.



Step 5 : Take drill with screw holder and fit fence
Stainless Steel screw into the holder. Securely fix screw through
Top Panel and Post Cover joining them as shown.



Step 6 : Take your Standard Panel and fit it tightly
to the folded lip at the base of the front of the Top
Panel as shown.



Step 7 : Once the Standard Panel is in position fix it securely to the Top Panel and Post Covers using the ball nosed Stainless Steel assembly screws provided as shown above. Follow this procedure for the next panels fitting them together.



Step 8 : Continue to secure all the Panels to the
Post Covers and upper Panel. We recommend
fixing each panel to the post covers using 6
screws.